CNCGLASS
CNC Ucolin Interlayer Technology Co., Ltd.
SHENZHEN, GD, CHINA
Peter Lin · cnc@cncglass.com · WhatsApp / Mobile +86 15013829504
WeChat wecan365 · www.cncglass.com

What Is an SGP Interlayer?

A stiffer chemistry, not a luxury label for PVB

Processors, facade designers, and buyers now ask what an SGP interlayer is, how it differs from PVB, and why some structural glass specifications insist on it. SGP, in architectural language, is an ionoplast sheet. It is not simply a higher-priced PVB. The polymer network is stiffer and stronger after lamination, so the finished plate carries load and retains fragments in a different way. That difference is useful only when the structure, the climate, and the process are chosen to match it.

SGP (ionoplast) and PVB: different design aims

Topic	PVB	SGP / ionoplast
Role	The established safety interlayer	Higher stiffness and residual capacity
Typical duty	Windshields, everyday facades, acoustics	Structural, long-span, severe weather
Process	Familiar nip and autoclave route	A tighter, often hotter, autoclave hold
Selection rule	Not automatically the weaker choice	Not automatically better for every opening

Figure 1. SGP (ionoplast) and PVB serve different design aims; neither is automatically the better film for every opening.

Tensile behavior, tear resistance, clarity, haze, thickness, weathering, and the actual lamination window all have to be read together. A single attractive number on a page is not a design.

How SGP and PVB differ, and what 'ionoplast' means here

Both films laminate glass. PVB is the long-established safety interlayer, with excellent adhesion and a familiar autoclave route, and it remains the right choice for many facades, windshields, and acoustic plates. SGP belongs to the ionoplast family. After a correct cycle it shows a higher modulus and a higher residual capacity once the glass is cracked. In short, PVB is the default safety film; SGP is the film to examine when stiffness, wind resistance, or post-breakage stability dominate the brief.

It is a mistake to say that SGP is always better. The two products were designed for different aims. Structural glass, railings, skylights, and large curtain-wall lites are the settings where the higher stiffness is most often justified. In this article, 'ionoplast interlayer' means that architectural sheet, not a membrane used for ion transport in other industries.




Figure 2. Four questions that should lead an SGP specification: residual capacity, thickness, plant capability, and batch consistency.

Strength figures, thickness, and a different process window

Tensile strength describes how the film resists breaking in tension; it influences how a cracked plate holds together under load. Tear strength describes resistance to a rip starting and running, which is closely tied to fragment retention. Neither figure should be read as 'larger is always better' in isolation. They have to be interpreted with modulus, thickness, and the glass construction. Product data should be taken from the current sheet and the matching test reports for that grade, not from a figure remembered from an informal note.

A thickness of 0.89 mm is a common ionoplast gauge. It is not a universal answer. Size, glass thickness, load, support, climate, and the required safety level all belong in the calculation. Railings, stairs, and floors usually need a stricter review than an ordinary window. Impact or blast designs may need a thicker ply or a multi-ply pack. Substituting a cheaper gauge for the designed one is not a harmless saving.

The process window is not a copy of a PVB recipe. Cleanliness of glass and film, thorough de-airing on large plates, a hold temperature matched to the ionoplast grade, and equipment that can actually deliver even heat and vacuum all have to be established on the line, preferably through a documented trial, before volume production starts.

Uses, durability, and how to judge a supply

Typical uses include curtain-wall laminates, large plates, skylights, railings, stairs and floors, other structural glass, high-safety laminates, and some impact-resistant constructions. Long-term appearance depends on more than the film: edge design, workmanship, the seal, the climate, and the way the unit is installed all matter, especially in heat, humidity, strong sun, or a coastal setting. If moisture can sit at a poorly detailed edge, the interface can still fail even when the polymer itself weathers well.

A reliable supply is judged by appearance and gauge uniformity, by the mechanical and optical figures that the project will use, by a plant trial, and by batch-to-batch consistency. Production control and technical support belong in that judgment. The questions we recommend writing down are simple: what safety level, what size and structure, what load, what thickness, whether the equipment can run the cycle, whether batches are consistent, and whether complete process guidance is available. A film that looks strong only in a laboratory note is not yet a project material.

An SGP interlayer is an ionoplast sheet with a higher stiffness and residual capacity than conventional PVB, intended for structural and high-safety laminated glass. It is not an automatic upgrade for every lite. Choose it by structure, load, thickness, process capability, and a consistent supply, and it will do the work it was designed for.

Contact Us

Brand: CNCGLASS

Company: CNC Ucolin Interlayer Technology Co., Ltd.
Address: SHENZHEN, GD, CHINA
Contact: Peter Lin
Email: cnc@cncglass.com
WhatsApp / Mobile: +86 15013829504
WeChat: wecan365
Website: www.cncglass.com

We can help match ionoplast grades and thicknesses to a stated glass structure, and review process windows if bubbles, adhesion, or optics are a concern.